

# Enhanced Willem Universal Eprom Programmer

Anyway Technology Company

## How to use the eprom programmer

- Check the parallel printer port setting in the BIOS, it should be EPP or Normal.
- Check there are any active resident programs that use the printer port, such as TWAIN drivers. You may have to remove it.
- Connect to the printer port with a 25 pin SubD cable, the cable should not be longer than 1.8 meter (6 feet standard cable). This must be a fully wired 1:1 cable. Note: A null modem or serial cable won't work.
- Connect the USB power cable, the Voltage-Normal LED and EPROM-Normal LED must go on.
- Run the program
- Select device type
- Click the Willem in toolbar to change to PCB3
- Set the DIP switch based on the displayed pattern.